


21-1 Ignition System, 2.0L Manual



Component

Connector


Ground

Splice

Page

Harness

21-2 Ignition System, 2.0L Manual



Component

Connector


Ground

Splice

Page

Harness

21-3 Ignition System, 2.0L Automatic



Component

Connector


Ground

Splice

Page

Harness

21-4 Ignition System, 2.0L Automatic



Component

Connector


Ground

Splice

Page

Harness

21-5 Ignition System, 2.5L



➡ Component

➡ Connector


➡ Ground

➡ Splice

➡ Page

➡ Harness

21-6 Ignition System, 2.5L



➡ Component

➡ Connector

➡ Ground

➡ Splice

➡ Page

➡ Harness

➡ How The Circuit Works